

# GRUNDIG SERVICE MANUAL




© Btx ★ 32700 #


Service  
Manual

Sach-Nr./Part no.  
72010-736.10

WKC 1650 VD  
WKC 3650





WKC 1650 VD (9.18252-8151 / G.HC 16-00)



WKC 3650 (9.18253-8151 / G.HC 17-00)


**Tastenplatte**  
**Key Board**






TYPENUNTERSCHIEDE:  
TYPE DIFFERENCES:  
WKC 1650 VD: BAUELEMENTEKENNZEICHNUNG V  
MARKING OF COMPONENTS V  
WKC 3650: BAUELEMENTEKENNZEICHNUNG A  
MARKING OF COMPONENTS A











TYPENUNTERSCHIEDE:  
TYPE DIFFERENCES:

WKC 1650 VD: BAUELEMENTKENNZEICHNUNG V  
MARKING OF COMPONENTS V

WKC 3650: BAUELEMENTKENNZEICHNUNG A  
MARKING OF COMPONENTS A

# **APF-Platte** **APF Board**










## Schaltplan Hauptplatte (19353-300) Teil 2

## Circuit Diagram Main Board (19353-300) Part 2









WKC 3650: BAUELEMENTEKENNZEICHNUNG A  
MARKING OF COMPONENTS A

## Schaltplan Hauptplatte (19353-300) Teil 3

## Circuit Diagram Main Board (19353-300) Part 3







3-7